

INSTALLATION INSTRUCTIONS

MAKE: Dodge MODEL: 2500/3500

YEAR: 1994-1998

ENGINE: L6-5.9L (td) Cummins

Turbocharger (Street Series) 46-60110



Parts Included:

- Turbocharger
- Gasket, Exhaust Elbow
- · Gasket, Oil Return
- · Gasket, Oil Feed
- Exhaust Elbow bolts
- · Gasket, Exhaust Manifold
- M10x1.50x37mm Stud
- M10x1.50 Small Flange Nut

Qty **Tools Needed:** 1

1

1

1

5

1

4

- 15mm Deep Socket
- 13mm Deep Socket
- 11mm Deep Socket
- 10mm Deep Socket
- 10mm Socket
- 8mm Socket
- 13/16" Wrench
- 3/4" Wrench
- 15mm Wrench
- 13mm Wrench
- 10mm Wrench
- 5/16" Nut driver
- Flat Head Screwdriver

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on this product. Thoroughly inspect** the aFe turbocharger to make sure there is no damage from shipping (if damage is noted, immediately contact aFe customer service).

- Disconnect the batteries before starting the installation.
- Remove air intake system.
- Disconnect the intercooler pipe from the turbocharger compressor outlet.
- Disconnect the exhaust downpipe from the turbocharger.
- Disconnect the oil supply from the top of the turbocharger.
- Disconnect the oil drain line from the bottom of the turbocharger.
- 7. Remove the turbocharger from the exhaust manifold.
- 8. Remove the oil flow restrictor from the top of the O.E. turbocharger.
- 9. Loosen the bolts and remove the turbine elbow from the O.E. turbocharger.
- 10. Thoroughly clean the sealing surface of the exhaust manifold outlet on the exhaust manifold.
- 11. Install the turbine elbow to the back of the aFe turbocharger using the supplied bolts and the supplied gasket.
- 12. Remove the studs from the exhaust manifold and install supplied studs.
- 13. Install the aFe turbocharger using the supplied gasket and hardware.
- 14. Connect the oil drain line to the bottom of the turbocharger using the supplied gasket and tighten the bolts.
- 15. Lubricate the turbocharger bearings by pouring several ounces of motor oil into the oil inlet of the turbocharger. Spin the compressor wheel by hand to properly lubricate.
- 16. Install the oil flow restrictor on the aFe turbocharger.
- 17. Connect the oil feed line to the oil flow restrictor and tighten.
- 18. Connect the exhaust downpipe to the turbocharger and tighten the two bolts on the flange.
- 19. Connect the intercooler pipe to the turbocharger compressor outlet.
- 20. Install the air intake system.
- 21. Connect the batteries.
- 22. Double check that all connections are secure.
- 23. Your installation is now complete. Start the vehicle and verify again that all connections are secure and that you have no leaks. Let idle for 5-10 mins. to allow the aFe turbocharger to properly lubricate before driving.



INSTALLATION INSTRUCTIONS

MAKE: Dodge **MODEL:** 2500/3500 **YEAR:** 1994-1998

ENGINE: L6-5.9L (td) Cummins

Turbocharger (Street Series) 46-60110

Warranty

Turbocharger warranty claims must be filed within 2 years from the invoice date. Please see the current "aFe Limited Lifetime Warranty" policy for details. Please call for inquiries and to be issued a Return Good Authoriztion (RGA) number from aFe prior to sending in the turbocharger. An inspection will be conducted to assess the repair. Should the turbocharger warrant be declared "void" (see conditions below), the turbocharger will be returned at the owner's expense. In event of a defect of an aFe turbocharger within the period covered by this limited warranty, arrangements will be made to repair/replace at the discretion of aFe.

This warranty is limited to repair and replacement without charge and shall only apply to defective part. aFe wll not replace the complete turbocharger should a single component is found to be defective. Limited warranty offer does not cover additional incurred cost such a logistics, labor charges, car storage fee, car rental fee, economic loss, ect.

The limited warranty offered by aFe is voided under these conditions:

- -Product has been installed improperly
- -Improper or lack of maintenance
- -Wear and tear due to normal usage
- -Product has been misused or neglected
- -Damage due to accident
- -Damage from foreign matter
- -Modifications have been made or attempted

Due to no formal means of monitoring product use, each claim will be independent and will vary case by case. The final assessment will be made by aFe.