INSTALLATION INSTRUCTIONS

MAKE: GM
MODEL: Duramax
YEAR: 2002-2004
ENGINE: V8-6.6L (td) LB7
*Note: Will ONLY fit vehicles w/ straight 2-1/2" coupling intake manifold

Intercooler Tube
46-20047



Parts Included:
- Intercooler Tube

Tools Needed:
- 8mm Socket
- 7/16" Deep Socket
- 3/8" Driver Ratchet
- 3/8" Driver Extension
- Flathead Screwdriver

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

1. Disconnect batteries on vehicle.
2. Disconnect sensors on intake tube.
3. Remove air box and intake tube from vehicle.
4. Loosen both clamps on I/C tube and remove tube.
5. Install aFe I/C tube with OE clamps and couplings.
6. Tighten clamps until spring is compressed. Install parts removed in step 3 and reconnect everything disconnected from steps 1 and 2.
7. Your installation is now complete, Enjoy!

Note: This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles.