

Battery Hold-Down

2011+ Ford Powerstroke 6.7L



*** Be sure to NEVER work on a hot engine, serious burns may result ***

1. Disconnect negative battery cables.
2. Un-bolt and remove stock hold downs.
3. Use existing stock hardware to fasten Sinister® Hold-Downs over battery.

