


## **SECTION 3**: READING THE VEHICLE INFORMATION

NOTE: Please make sure that all stock electronics are turned off and disconnect any aftermarket electronics as well.

## POWERING UP THE SCORCHER PRO

1. Using the provided HDMI/OBDII Cable from Section 1, plug the device into the vehicle's OBDII Port commonly found within 24" of the steering column under the driver's side dash.



## READING THE VEHICLE'S INFORMATION

- 1. At this point, the key should be in the ignition, but in the OFF position until prompted to turn key ON/RUN position.
- 2. From the Main Menu, select Program Vehicle.

3. Processing Data: The Scorcher Pro is now reading your MAIN MENU	
vehicle information. PROGRAM VEHICL	E
<ul> <li>Updates: Internet Required. In order to install the most upto-date files the Scorcher Pronow requires internet</li> <li>GAUGES / DATA LONG</li> <li>VEHICLE FUNCTION</li> </ul>	OG
access. You can access PROGRAM VEHICLE PROGRAM VEHICLE	
methods found UPDATE REQUIRED	
in Section 4. Update required. Please check S for updates	S
EXIT CONTINUE	

# **SECTION 4**:

## THREE METHODS FOR UPDATING THE SCORCHER PRO

PROGRAM VEHICLE

**CONNECT TO WIFI** 

#### METHOD #1: UPDATING VIA WIFI **INSIDE THE VEHICLE**

- 1. Select Continue from the Internet Required screen.
- 2. Select the WiFi network you would like to connect to. Use the middle button to confirm your selection.
- 3. Enter the network pass code using the arrow keys and the middle button to select.
- 4. Confirm the Wifi settings and select Continue.

### METHOD #2: UPDATING VIA WIFI USING USB POWER

- 1. Plug the Scorcher Pro into a computer or wall charger using the provided Micro USB Cable.
- 2. Select "Program Vehicle" from the main menu.
- 3. "Vehicle Updates" select "Confirm"
- 4 "Device Updates" select "Continue"
- 5. "Internet Required" select "Continue"
- 6. Follow on screen instruction to set up WiFi.
- 7. Follow on screen prompts until the "Up-To-Date" screen.
- 8. Unplug and return to the vehicle .

## METHOD #3: UPDATING USING UPDATER SOFTWARE

## NOTE: Unplug the device from your computer before proceeding.

- 1. Go to: http://afepower.com/tunersupport and click on the "Support" tab at the top of the page.
- 2. Locate and click the "Scorcher Pro" option and then select "Downloads". You will see "Download Now" under the "Updater" section. Click "Download Now" to begin downloading and installing updater on your computer.
- З. Wait for the program to download. Then double click & "Run" the Executable file if it does not open automatically.
- 4. Follow the on-screen directions of the Device Update Software Installer until it allows you to click "Finish".
- 5. Connect your Scorcher Pro to your Windows™ based PC using the provided Micro USB<sup>™</sup> cable. We do not offer support for Apple computers at this time.
- 6. Double click and open the Device Updater Software.
- 7. Click "Automatically Check for Updates".
- 8. Confirm the update by pressing the "Update" button. The update will now begin.
- 9. Let the updater run until it says "Your device is now up to date".
- 10. Unplug the device from your computer & proceed to Section 5.

- SSID (NETWORK NAME) aFe XXXXX

### EXIT CONTINUE



## **SECTION 5:** TUNING THE VEHICLE

- Cloud Check If your dealer has sent you a custom tune using the cloud select "continue" to download the custom tune. If not select "Skip" and follow prompts.
- Select your tune from the 2. following menu items:

#### Pre-Loaded Tune Files

Preloaded aFe Power tunes for use on stock vehicles only.

#### Custom Tune

Custom Tuning Dealer files, if there are any on the device

SKIP

#### Return to Stock

Restore original factory file to vehicle.

З. Highlight the tune you wish to use and select confirm.

street use notice.	PROGRAM VEHICLE
Depending on your vehicle there	STREET USE NOTICE
may be further parameters you can change under "Additional Tune Option". Select "Change" to view the available options or "Skip" to continue with downloading the tune only.	This device is NOT LEGAL for sale or use in California on any pollution controlled motor vehicles. Press CONTINUE to start programming.
The Tune and any Additional Tune Options will now be installed. Follow the on-screen directions to finish the process.	EXIT CONTINUE
E: During the installation the	Your device is not paired. Select CONFIRM to pair vour

device with this vehicle.

CONFIRM

Read and acknowledge the

your (One) vehicle. Once married

there is an unlock fee to un-marry

the device from your vehicle in or-

der to install it on another vehicle.

4.

5.

6

**PROGRAM VEHICLE** 

**CLOUD CHECK** 

Press CONTINUE to query Cloud for available custom tunes.

CONTINUE

## SECTION 6: LOADING CUSTOM TUNES

#### NOTE: Make sure the "Updater Software" from Section 4 Has been completed before proceeding with Section 6.


The Scorcher Pro is capable of having custom tune files sent over the Cloud straight to the device from aFe. If aFe has chosen to email your file, you can load them onto the device using the Device Updater software.

- 1. From your e-mail, save your Custom Tunes (.cef files) to your computer's Desktop.
- 2. Open the Updater software and click the Load Custom Tune File button.
- 3. Click Browse and locate your custom tunes on your Desktop. Alternatively, you can also click Locate Custom Tunes.
- 4. Highlight the Tune you wish to load. The tune you selected should move to the Available Tunes section.
- 5. Select the listed tune in the Available Tunes section, then click the >> button to move the selected tune to the On Device section.
- 6. Highlight the tune under the On Device section, then click program. Tunes can only be loaded one at a time. Repeat steps 3-7 for each tune, the device can hold up to ten custom tunes.

Transfer File to Device	Available Tunes Custom tune 1	On Device
Update Firmware	Add to Device	
vanced Operations	<	
play Device Setting and Serial Number	Remove Tune	
Get Stock File from Device		
	Edit Name	
	Press "Program" to update	Program
	CEF Id: 2784372564	< Back

NOTE: To edit the name of the file as it appears on your device, you must highlight the file after transferring the file to the On Device section of Updater. Next to Edit Name, change the name of the file here. Select Save, then Program.

## **SECTION 7**: **ON-DEVICE DATA LOGGING**



## **SECTION 8:** ADJUSTABLE OPTIONS EXPLAINED

### DIESEL VEHICLE SPECIFIC OPTIONS

Performance/Extreme The most aggressive preloaded diesel tune. Good for everyday use. racing, or economy but not recommended for any type of towing.

Street/Performance The Street tune has less power than Performance with a moderate gain over stock, safe for light towing, under 5,000 lbs.

Towing/Tow This tune should be used when towing any significant load as the shifting is specific for towing.

Trans Only For heavy loads, the engine and boost are left stock and only the transmission shift points are tuned.

Jake Brake Helps to increase engine braking while coasting to help lower braking temperatures.

Locked at CT Keeps the torque converter locked during deceleration to aid in engine braking.

Lock In 1-2-3 Locks the torque converter in 1<sup>st</sup>, 2<sup>nd</sup> and 3<sup>rd</sup> gear.

Agg. Tow Haul More aggressive shift schedule keeping the engine in its power band longer.

## **DIESEL & GAS VEHICLE OPTIONS:**

Axle Ratio Corrects shift patterns / speedometer for aftermarket axles / parts. (Not available on all vehicles)

Tire Size Sets tire size to correct shift patterns/speedometer. (Not available on all vehicles)

Idle Speed Sets idle speed in RPM.

**Traction Control** On/Off setting disables traction control without using the TCS button.

WOT Shift Increase or Decrease the WOT shift points of each gear individually by MPH.

Shift Pressure % change in transmission pressure during shifts. (+ equals firmer, - equals softer)

## GAS VEHICLE SPECIFIC OPTIONS:

Tune Type Performance levels vary by the octane you select. Higher octane will provide higher performance increase.

Towing Tune Adjusts the octane based tunes to focus more on towing over performance.

Global Spark Add or remove timing advance to the entire RPM range.

Spark by RPM Add or remove timing by RPM range. (0-2000) (2000-4000) (4000-8000)

WOT Fuel Add or remove fuel at wide open throttle. (WOT)

Fuel Injectors Allows you to adjust for different sized injectors. (Not available on all vehicles)

**CMCV** Deletes Updates tune to handle the CMCV/IMRC delete plates modification.

Fan Control Lowers the temperature at which the fan turns on.

**Rev Limiter Drive** Sets rev limit in RPM while in drive.

Rev Limiter Neutral Sets rev limit in RPM while in neutral.

Speed Limit Remove, increase, or decrease the vehicle speed limiter. (AKA Governor)

not available on all vehicles.

## **SECTION 9:** FREQUENTLY ASKED QUESTIONS

#### Q: When I try to update my tuner, it says "Please connect device" but it's already plugged in.

A: This is an issue with your PC's driver software. If problem persists, contact Tech Support at (951) 493-7100 or go to afepower.com/contact/tech-warranty.

#### Q: When I connect the tuner to the vehicle, it doesn't power on.

A: Check for blown fuses specific to the OBDII Port/Cigarette Lighter for your vehicle.

#### Q: Does the tuner have to stay plugged in to keep the vehicle tuned?

A: No, after tuning the vehicle you can disconnect the programmer and store it.

#### Q: Can I stack/combine the Scorcher Pro with another chip or tuning module? A: All chips/tuning products must be removed prior to tuning with any device.

#### Q: Can the vehicle be tuned while the engine is running?

A: We do not recommend tuning the vehicle while the engine is running as this can cause severe damage to the vehicle and the PCM.

#### Q: Should I return to stock before taking my car to the dealer?

A: We recommend that you always return your vehicle to stock before returning to the dealership as this prevents the tuner from becoming locked if the dealer updates the PCM.

#### Q: My device is telling me my car is a Shelby GT500 when I go to program vehicle or My device says Demo Mode when I read Device Info.

A: Check device settings and look for Demo Mode. If it is on disable it by turning it to off. This will cause the device to stop identifying your vehicle as a Shelby GT500 and will now operate as needed.

#### Q: My vehicle is modified and I loaded a preloaded tune. Now it won't run as expected.

A: In most cases a modified vehicle requires a custom tune. There are set ups in the preloaded tune options to adapt to certain cold air intakes, however this is per vehicle and what works for one vehicle may not work on another. Please contact a Custom Tune Dealer for a custom tune if your vehicle is heavily modified.


#### Q: I brought my vehicle to get work done at a dealership and they flashed the vehicle now the device is telling me it is the incorrect vehicle.

A: Technical Support at: (951) 493-7100.

#### Q: Can I tune more than one vehicle with this programmer?

A: No, during the installation the Scorcher Pro will be married to your vehicle. Once married there is an unlock fee to un-marry the device from your vehicle in order to install it on another vehicle.





Make: Ford Model: Super Duty F-250/F-350/F-450/F-550 Year: 2017-2018 Engine: V8-6.7L (td) Power Stroke




- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call technical support at 951-493-7100 or e-mail tech@afepower.com.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect both the negative battery terminal before proceeding.

# Retain factory parts for future use.

Label	Qty.	Description	Part Number
<u>A1</u>	1	Pro 10R (Blue Media)	20-91061
<u>A2</u>	1	Pro DRY S (Gray Media)	21-91061
В	1	Tube	05-73006B1
С	1	Housing	05-73006B2
D	1	Plug, Urethane	05-01225
E	1	Coupling, Silicone Hump	05-01204
F	1	Washer: M6	03-50070
G	2	Screw, Torx: M4	03-50491
Н	1	Screw, Hex Hd: M6	03-50057
<u> </u>	1	Fixing Clamp, 3/4"	03-50234
J	2	Clamp, T-bolt (4-13-16" - 5-1/8)	03-50261
K	1	Clamp, T-bolt (8-5/16" - 8-5/8")	03-50267

Installation will require the following tools:

7mm, 8mm, 10mm, 7/16 nut driver or socket and extension.







## Refer to Figure A for Step 1

Step 1: Remove the two 8mm bolts securing the OE filter housing, and loosen the two clamps on the OE tube.



### Refer to Figure B for Step 2

Step 2: Push the small hoses out of the way on the OE tube, and remove the tube.





## Refer to Figure C for Steps 3-4

- Step 3: Slide back the red locking tab on the bottom side of the MAF sensor connector, and then dis connect the sensor.
- Step 4: Remove the OE air box, pulling in an upward motion.



## Refer to Figure D for Steps 5-6

Step 5: Remove the factory grommets from the OE air box and install on the Momentum HD housing.Step 6: Slide the filter into the housing and install provided T-bolt clamps. Tighten only the larger T-bolt clamp.





## Refer to Figure E for Step 7

Step 7: Install the Momentum HD housing into the vehicle by pushing it in to the factory grommet.



## Refer to Figure F for Steps 8-10

Step 8: Transfer the factory filter minder and grommet (1)on to the Momentum HD tube.

- Step 9: Transfer the MAF sensor (2) from the OE housing to the Momentum HD tube using the provided screws.
- Step 10: Install silicone coupling (3) and T-bolt clamps (4) onto the small end of the tube. Do not tighten clamps.





## Refer to Figure G for Steps 11-15

- Step 11: Install Momentum HD tube by first sliding the coupling over the turbo inlet. Connect the other end to the air filter.
- Step 12: Tighten all clamps.
- Step 13: Reconnect the MAF sensor (5).
- Step 14: Secure hose to the tube with provided fixing clamp(6), 10mm bolt(7) and washer(8).
- Step 15: Reinstall the factory two 8mm bolts removed in Step 1 securing the air box.



## Refer to Figure H for Steps 16-18

Step 16: If you have purchased the aFe air scoop (P/N: 54-73006-S), install it referring to its install instruction sheet.

- Step 17: If you don't have the air scoop, you have the option to close off the extra air inlet with the furnished plug or to keep it open.
  - Without the plug installed, the aFe Power intake will capture the maximum air available. More airflow offers more power. Yet some of this air is picked up from inside the engine compartment and could be warmer air. Warmer air will affect the performance of the vehicle.
  - The plug installed on the housing will block off any hot engine air entering the housing and make sure the coolest air available is directed into the engine. It will also reduce the noise of the intake.


Step 18: Verify all connection are secured. The installation is now completed.

#### NOTE:Place enclosed CARB EO sticker on or near the device on a smooth, clean surface. EO identification label is required to pass the smog inspection.



advanced FLOW engineering, inc.<sup>-</sup> 252 Granite Street Corona, CA 92879





## advanced FLOW engineering Instruction Manual P/N: 54-73006-S

Make: Ford Model: Super Duty F-250/F-350/F-450/F-550 Year: 2017-2018 Engine: V8-6.7L (td) Power Stroke




- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.

# Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Scoop, Rotomold	05-73006B3
В	1	Seal, Trim: 7/16" (8-1/2" in.)	05-00072

Installation will require the following tools: Panel popper tool.

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.








## Refer to Figure A for Step 1

Step 1: Remove the two push clips securing OE scoop.



## Refer to Figure B for Step 2

Step 2: Squeeze the two locking tabs inward and remove OE scoop by pulling in upward motion.





## Refer to Figure C for Step 3

Step 3: Install aFe scoop into Momentum HD housing and then push scoop down until the two tabs lock into place.

NOTE: Make sure scoop is positioned behind the plastic OE radiator panel.



## Refer to Figure D for Steps 4-5

Step 4: Replace the two OE push clips removed in Step 1.

Step 5: Install supplied trim seal along the top edge of scoop inlet.

Your installation is now complete. Thank you for choosing aFe POWER!



advanced FLOW engineering, inc.<sup>-</sup> 252 Granite Street Corona, CA 92879