

INSTALLATION INSTRUCTIONS

SUBJECT: Lower Heater Core Return Hose for 2003-2012 Cummins

FPE-2025-149
August, 2025
Page 1 of 2

FITMENT: 2003-2012 5.9L and 6.7L Cummins Equipped Dodge Ram 2500/3500 Pickup Trucks

KIT P/N: FPE-CUMM-LHCL-0312

EST INSTALL TIME: 1 Hour

TOOLS REQUIRED: Pliers, 1/4" hex drive or socket, flathead screwdriver

KIT CONTENTS:

Item #	Description	QTY
1	Lower heater core hose	1
2	Hose clamp	2



PART CROSS-REFERENCE:

Replaces the following part numbers

Mopar 68186700AA, Mopar 55056673AC, Mopar 55056965AA

WARNINGS:

- Use of this product may void or nullify the vehicle's factory warranty.
- User assumes sole responsibility for the safe & proper use of the vehicle at all times.
- The purchaser and end user releases, indemnifies, discharges, and holds harmless Fleece Performance Engineering, Inc. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. Fleece Performance Engineering, Inc. will not be liable for any direct, indirect, consequential, exemplary, punitive, statutory, or incidental damages or fines cause by the use or installation of this product.

PROCEDURE:

STEP 1: Disconnect both batteries and drain the coolant from the coolant system using the drain knob on the rear, driver's side of the radiator

STEP 2: Locate the lower heater core return hose in the engine bay located on the (left) passenger side of the engine on the top of the coolant standpipe. Loosen and remove the hose clamp from the lower hose at the firewall heater core connection and the top of the coolant standpipe.

STEP 3: Disconnect the lower heater core hose from the coolant standpipe and the firewall.

STEP 4: Install the new Fleece Performance heater core return hose. Install the included hose clamps onto the hose. Connect the hose to the lower heater core port on the firewall and the coolant standpipe. Tighten the hose clamps using a ¼" socket or flathead screwdriver.

STEP 5: Refill the coolant system and reconnect the battery terminals.

STEP 6: Start the vehicle and verify that no leaks are present. Add coolant as necessary.

